



# BRENER TOOLS™

## INSTRUCTIONS

### STEP ONE:

Carefully screw the bolts into predrilled 10" or 12" the core bit.

---

### STEP TWO:

Ensure all screws are fully bolted in.

---

### STEP THREE:

Properly align the inner core bit with the center point of the Smakt.

---

### STEP FOUR:

Enjoy all the free time you now have.

---

### KIT INCLUDES:

- 1 ..... Smakt
- 14 ..... Stainless Steel Bolts
- 1 ... 10" x 6" Short Core Bit
- 1 ... 12" x 6" Short Core Bit
- 1 ..... Allan Key